

F I G. 2




FIG. 3A








FIG. 3B






F I G. 5






## F I G. 7




**FORWARD** 




## F I G. 9

SLOT NUMBER	DISK MOUNTING		
	TYPE	STATES OF SIDE-A AND SIDE B	
1	DVD	А	INFORMATION RECORDING FACE
		В	INFORMATION RECORDING FACE
2	CD	Α	INFORMATION RECORDING FACE
		В	LABEL FACE
3	VCD	А	INFORMATION RECORDING FACE
		В	LABEL FACE
4	SVCD	Α	INFORMATION RECORDING FACE
		В	LABEL FACE
5	SACD	Α	INFORMATION RECORDING FACE
		В	LABEL FACE
6	VACANT	А	UNDEFINED
		В	UNDEFINED
] ] ]		l   	
! ! ! !	]	!	
300	C D	Α	INFORMATION RECORDING FACE
		В	LABEL FACE

FIG. 10




## FIG. 11



**FORWARD** 

F I G. 12A **START** B 1 TURN ON THE POWER B 2 ACCEPT A DISK REPRODUCTION REQUEST B 3 CHECK A DISK FOR PRESENCE OR ABSENCE B 4 MOUNT A DISK (FORWARD) B 5 DISK CHECK B 6 IS SIDE-A REPRODUCTION **ENABLED** ? NO B 8 YES В 7 WRITE DATA INTO MEMORY B 2 2 В 9、 REPRODUCE WARNING SIDE-A PULL OUT DISK (FORWARD) **PROCESS** B 1 0 MOVE DISK TO TURN TABLE B 1 1 TURN THE TURN TABLE BY 180 DEGREES B 1 2 MOUNT A DISK (BACKWARD) B 1 3 DISK CHECK

F I G. 12B



F I G. 13





FIG. 14



F I G. 15A






FIG. 15B





F I G. 17

